



# Sound Panel Plus User Guide

---

This guide has been written to help you get the most from your Sound Panel Plus. Please ensure that you read this fully as it contains important information on fixing the panel to your wall. Failure to follow this advice may result in damage to the panel and invalidate your warranty.

**Keep this guide in a safe place for future reference.**

# Contents

---

Unpacking	3
Setting up	4
Potential risks & warnings	5
Contact details	6

# Unpacking

---

1. The Sound Panel Plus is shipped in specialist packaging, designed to protect the wall from damage during transport.
  2. Ensure that the packaging is carefully removed from around the Sound Panel Plus. Keep the packaging in case the Sound Panel Plus needs to be returned.
  3. Take care not to lift the Sound Panel Plus by the sides as this can cause damage. Always lift from the top and bottom.
  4. If you find any damage when you unpack you should report it within **7 days** to your supplier.
-

# Setting up

---

1. The Sound Panel Plus must be attached to a solid wall using fixings appropriate to the construction of the solid wall.
2. Attach the metal bar to the wall, ensuring accurate measurements. The Sound Panel Plus should be hung on this bar once it is attached to the solid wall correctly.
3. Ensure that the power cable from the Sound Panel Plus is plugged into a suitably grounded socket. There should be no tension in the power cable.
4. The Sound Panel Plus is now ready to use. The Sound Panel Plus is activated by sound, simply clap, stomp, shout or play your own music to activate the coloured lights.
5. There are a variety of visual modes on the Sound Panel Plus. Simply switch between the modes by using the white button found on centre of the panel.
6. You can also adjust the sensitivity and the brightness by turning the two knobs that are located to the right side of the white button.
7. If you have an external microphone that you want to use to further interact with the Sound Panel Plus, simply plug this in to the socket on the left hand side of the panel. When you speak through the microphone the panel will react to the noises you make.

# Potential risks & warnings

---

1. Read and understand all these instructions before using the Sound Panel Plus.
2. Do not operate the panel with a damaged power cord, or if the unit has been dropped or damaged.
3. Position the power cord so that it will not be tripped over, pulled or come into contact with hot surfaces.
4. If an extension lead is necessary, a cable with a current rating at least equal to that of the wall (3.5A) should be used.
5. Always unplug the wall from the power socket before cleaning, servicing and when not in use. Never yank the cord to pull the plug from the outlet. Grasp the plug and pull to disconnect.
6. Always connect the Sound Panel Plus to a grounded outlet.
7. To reduce the risk of electrical shock, do not immerse the product in water or other liquids.
8. Do not dismantle the Sound Panel Plus. Contact the supplier or manufacturer if servicing is required. Incorrect assembly can cause electrical shock when the product is used.

**This Sound Panel Plus is supplied by:**



Manufactured by:

Apollo Creative  
Knaresborough Technology Park  
Manse Lane  
Knaresborough  
North Yorkshire  
HG5 8LF

**T:** 01423 798232

**E:** [sales@apollocreative.co.uk](mailto:sales@apollocreative.co.uk)

**W:** [www.apollocreative.co.uk](http://www.apollocreative.co.uk)

